


Gateway Explanation

Initialize gateway

1. Press the reset button for about 8 seconds till both LED's are off.
2. Within a few seconds the blue LED starts flashing, gateway is initializing.
3. If both LED's (green and blue) are burning, initializing complete.

Please note:

- If blue LED keeps flashing, there is not connection with router. Check your internet connection.



Specifications

- Power supply: 85 - 265 V ~ 7,5W
- LED Type: RGB
- Socket Type: E27
- Beaming angle: 260°
- The brightness 588 Lumen

Specificaties

- Power input: 85 - 265 V ~ 7,5W
- LED Type: RGB
- Socket Type: E27
- Licht hoek: 260°
- De lichtintensiteit 588 Lumen

Technische Daten

- Stromzufuhr: 85 - 265 V ~ 7,5W
- LED Type: RGB
- Socket Type: E27
- Bereich: 260°
- Die Lichtintensität: 588 Lumen

Spécifications

- Alimentation électrique: 85 - 265 V ~ 7,5W
- LED Type: RGB
- Socket Type: E27
- Portée: 260°
- L'intensité lumineuse: 588 Lumen

Especificaciones

- Fuente de alimentación: 85 - 265 V ~ 7,5W
- LED Type: RGB
- Socket Type: E27
- Alcance: 260°
- El brillo: 588 Lumen

Specifikationer

- Strømforsyning: 6.4V ~ 6W
- LED Type: RGB
- Socket Type: E27
- Rækkevidde: 260°
- Lysintensiteten: 588 Lumen

Tekniset tiedot

- Tekniset tiedot: 6.4V ~ 6W
- LED Type: RGB
- Socket Type: E27
- Ulottuvuus: 260°
- Valon voimakkuus: 588 Lumen

Accessories

- Adapter
- USB cable
- LAN cable
- Quick start guide
- WiFi Bridge 5V

Accessoires

- Adapter
- USB kabel
- LAN kabel
- Quick start guide
- WiFi Bridge 5V

Zubehör

- Adapter
- USB-Kabel
- LAN-Kabel
- Quick start guide
- WiFi Bridge 5V

Accessoires

- Adaptateur
- Câble USB
- Câble LAN
- Guide de démarrage rapide
- WiFi Bridge 5V

Accessoires

- Adaptador
- Cable USB
- Cable LAN
- Guía de inicio rápido de
- WiFi Bridge 5V

Tilbehør

- Adapter
- USB-kabel
- LAN-kabel
- Quick start håndbog
- WiFi Bridge 5V

Lisävarusteet

- Sovitin
- USB-kaapeli
- LAN-kaapeli
- Pikaopas
- WiFi Bridge 5V